

Product Data Sheet

PIPE GUIDES

1. **Product Name:** MIRO Model Pipe Guides
2. **Manufacturer:** MIRO INDUSTRIES, INC.
844 South 430 West, Suite 100,
Heber City, Utah 84032
Phone: (800) 768-6978
Fax: (800) 440-7958
3. **Product Description:** MIRO Industries Pipe Guides are designed to attach to MIRO Industries Pillow Block and Roller Series Supports to prevent supported pipe from becoming disengaged from the pipestand. All Pipe Guides will ship separately and will need to be installed on site. It is important to note that pipe guides should not be rigidly-attached to the pipe installed in the pipestand to allow for lateral thermal expansion and contraction of the pipe to occur within the pipestand. Pipe Guides are stocked in accordance with the optimally sized pipe for each support. ***Custom pipe guides are available upon request. Please call MIRO Industries for more information.**
4. **Installation:**
 - Pillow Block Models 1.5, 3-R-2 and 3-R-4: Attach the Pipe Guide to the appropriate support using the included #8 phillips head stainless-steel screws into the molded holes on the top of the polycarbonate support.
 - Roller Series Support Models: Remove the nut from the vertical all-thread above the roller assembly. Install the appropriate Pipe Guide onto the vertical all-thread, and replace the nut securing the pipe guide in place.
5. **Availability:** MIRO Pipe Guides are marketed throughout the United States through representatives and distributors.
6. **Maintenance:** Normal maintenance is not required. Semi-annual inspection is required to check pipestand position and pipe alignment, check proper weight distribution and for improper installation that may cause system failure or damage.
7. **Technical Services:** Please call MIRO INDUSTRIES, INC: (800) 768-6978 or visit our website www.miroind.com for technical information and for graphic and CAD drawing downloads.